
HCSA Tracer Wire Installation Detail for Private Sewer Lateral Connection



- 1. THE CLEANOUT MUST BE LOCATED ABOVE HYDRAULIC GRADIENT OF DISPLACEMENT MAIN.
- THE CLEANOUT SHOULD BE LOCATED TO PROVIDE EASY ACCESS FOR INSPECTION AND MAINTENANCE.
- HDPE METER BOX, MID-STATES #111812 OR RAVEN METER BOX #1118X12 OR APPROVED EQUAL.